

Can't connect? Need help?

Wi-Fi

atomi™

Date Code: 01/19

Smart Coffee Maker

User Manual



**DO NOT RETURN THIS
PRODUCT TO THE STORE**

Call 1-800-757-1440
Mon-Fri 9:00-5:00 EST (US)
or email info@atomiusa.com



atomi™
Smart

Download Free APP

Watch Video

Open your smartphone camera
and point it at the QR Code

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and / or injury to persons, including the following:

1. **READ ALL INSTRUCTIONS BEFORE USING.**
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock, do not immerse cord, plug, or heating base in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the manufacturer (see warranty) for examination, repair, or adjustment.
7. Do not use outdoors.
8. Do not let cord hang over edge of table or counter or touch heated surfaces.
9. Do not place on or near a hot gas or electric burner or in a heated oven.
10. Do not move an appliance containing hot liquids. Allow to cool before moving.
11. Do not use appliance for other than intended use.
12. Avoid sudden temperature changes, such as adding refrigerated foods or cold liquids into a heated pot.

13. To disconnect, remove plug from wall outlet.
14. The use of accessory attachments are not recommended by the manufacturer as it may cause injuries.
15. Keep 6 inches clear from the wall and 6 inches clear on all sides.

NOTE: This appliance is for **HOUSEHOLD USE ONLY**.

- Some countertop and table surfaces are not designed to withstand the prolonged heat generated by certain appliances. Do not set the heated unit on a finished wood table. We recommend placing a hot pad or trivet under your carafe to prevent possible damage to the surface.
- During initial use of this appliance, some slight smoke and/or odor may be detected. This is normal with many heating appliances and will not recur after a few uses.


WARNING: To reduce the risk of fire or electric shock, do not remove any service covers. There are no user serviceable parts inside the coffee maker. Only authorized personnel should repair the coffee maker.

SAVE THESE INSTRUCTIONS

Thank you for purchasing the atomi Smart Coffee Maker

The atomi Smart Coffee Maker lets you brew your next cup of coffee from your phone anytime, anywhere! Set weekly schedules, turn your Smart Coffee Maker on and off automatically, and much more.


Inside the box you'll find:



Smart Coffee Maker



Reusable Filter



Glass Coffee Carafe - 12 CUP

Cleaning your Smart Coffee Maker before first use


Make sure your first cup of coffee is as good as it can be by cleaning your Smart Coffee Maker before its first use. Just follow these simple steps:

1. Wash the carafe, carafe lid and the filter basket in a mixture of mild detergent and water. Rinse each thoroughly.
2. Run a brew cycle with water only, without adding coffee and coffee filter.
3. When brewing is complete, turn your Smart Coffee Maker off, discard the water in the carafe and rinse the carafe, carafe lid, and filter basket.

Before you begin


1. Know your Wi-Fi network and password.
2. Make sure your mobile device is running iOS® 8 or higher or Android™ 4.1x or higher.
3. Make sure you're connected to a 2.4GHz Wi-Fi network (atomi smart app can't connect to 5GHz networks).

Step 1: Plug In



Plug your atomi Smart Coffee Maker into any standard outlet.

Step 2: Download App



Download the atomi smart app from the App Store or Google Play.


Step 3: Register



Enter your mobile phone number or email address.



Enter the verification code and create a password.




Log into the app.


Step 4: Add Device




Select "Add Device" or click (+) at the top right corner of the Devices screen.



Choose "Smart Coffee Maker" from the Device list.




Hold the strong button for 10 seconds until the LCD screen flashes "0000", then press "Continue" on the atomi smart app.



Enter your Wi-Fi network and password.



The atomi smart app will connect your device.



Preparing Smart Coffee Maker for use

Selecting and Measuring Ground Coffee

For best results, use a level tablespoon for ground coffee measurement. Make sure you use medium grind coffee for a perfect brew.

To Brew	Ground Coffee	
12 Cups	9 tbsp.	1 level tablespoon (tbsp) = 5 gr./0.17 oz.
10 Cups	7.5 tbsp.	1 cup = 5 fl. oz. of brewed coffee
8 Cups	6.5 tbsp.	Use more or less coffee to suit your taste.
6 Cups	4.5 tbsp.	
4 Cups	3 tbsp.	

Adding Water and Ground Coffee

1. Open the top lid of the Smart Coffee Maker.
2. Place a 10–12 cup paper basket-style filter or the included reusable filter into the removable filter basket.

NOTE: If using paper filters, it is important that the sides of the filter fit flush against the side of the filter basket. If filter collapse occurs, dampen the filter before placing in the filter basket. Add the desired amount of coffee and gently shake to level the coffee.

3. Fill the water reservoir with cold, fresh water to the desired capacity (1 cup equals 5 ounces). For easy and accurate filling, the water markings on the water reservoir show the amount of water needed to make the corresponding desired number of cups. Do not fill past the “12 cup MAX line” or water will flow out of the Smart Coffee Maker.

NOTE: The amount of coffee brewed will always be slightly less than the amount of water poured in the water reservoir. This is due to the absorption of water by the coffee grounds.

Using your Smart Coffee Maker without the atomi smart app

1. After completing the steps in the Adding Water and Ground Coffee section and with the carafe and the filter basket securely in place, turn the Smart Coffee Maker on by pressing the POWER button once. The POWER button light will turn on to signal that the Smart Coffee Maker is on and brewing.

NOTE: Brew can be stopped by pressing the POWER button a second time.

2. After the used coffee grounds have cooled, carefully remove the filter basket and discard them.

NOTE: The brew basket drawer is hot after brewing. Always allow the Smart Coffee Maker to cool down before cleaning.

3. Make sure the Glass Coffee Carafe is empty and in place before starting to brew coffee.
4. Be sure to turn your Smart Coffee Maker off when no longer using it.

Cleaning and Maintaining your Smart Coffee Maker

Daily Cleaning

Always unplug the Smart Coffee maker and allow to cool before cleaning.

- Remove and wash the filter basket, permanent filter, carafe and carafe lid in a solution of hot water and mild liquid soap.
- Never use abrasive cleansers, steel wool pads or other abrasive materials.
- DO NOT put carafe and lid in the dishwasher.

CAUTION: Never immerse the Smart Coffee Maker itself in water, in any other liquid or place in the dishwasher.

Cleaning the Glass Coffee Carafe

Hard water can leave a white stain on the carafe, and coffee may then turn this stain brown.

To remove carafe stains:

1. Fill the carafe with a solution of equal parts water and vinegar and let the solution stand in the carafe for approximately 20 minutes.
2. Discard the solution, then wash and rinse the carafe. Do not use harsh abrasive cleaners that may scratch the carafe.


Change Set Time

Set time through atomi smart app.

Open up the atomi smart app, choose your Smart Coffee Maker then select the clock icon to automatically configure clock settings.

Set time manually.

1. Hold down the HOUR button until “00:00” is blinking on the display.
2. Set current hour by pressing the HOUR button.
3. Press POWER button to select and save.
4. Hold down the MIN button until “00:00” is blinking on the display.
5. Set current minute by pressing the MIN button.
6. Press POWER button to select and save.



Troubleshooting

Cannot connect to your Wi-Fi network.

Make sure you entered the correct Wi-Fi password during the Wi-Fi setup. Check if there are problems with your internet connection. If the Wi-Fi signal is too weak, reset your Wi-Fi router and try again.

The “POWER” light does not light up.

The Smart Coffee Maker is unplugged. Plug the Smart Coffee Maker back into the wall outlet.

The Coffee is not brewing.

1. The Smart Coffee Maker is unplugged. Plug the Smart Coffee Maker back into the wall outlet.
2. There's a power outage. Wait for power to be restored.
3. The filter basket is not properly inserted. Insert filter basket correctly.
4. Carafe is not placed all the way on the warming plate. Place carafe correctly on warming plate.

The Smart Coffee Maker only brews water.

There are no coffee grounds in the filter basket. Add the desired amount of coffee to the filter.

There are grounds in the coffee.

The filter is not properly placed in the basket. Seat the filter properly within the filter basket.

FCC Notice:

This device complies with Part 15 of the FCC Rules. Operation is subject to the two following conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

CAUTION: Suitable for indoor use only.

DO NOT IMMERSE IN WATER. DO NOT EXCEED RATED CAPACITY.

For questions or concerns, email us at info@atomiusa.com
Manufactured and marketed by Atomi, Inc.
10 West 33rd St. Suite 520, New York, NY 10001
atomi™ is a trademark of Atomi, Inc.
Designed by atomi in New York. Made in China

One-year limited warranty from date of purchase against defects in materials and workmanship. Google is a trademark of Google LLC. Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates.